



ASSEMBLY

NOTES:

1. PURCHASED PART FROM 80/20
2. ACCESS HOLE TO TIGHTEN SCREW REQUIRED
3. END OF 80/20 MUST BE TAPPED FOR SCREW
4. END ACCESS REQUIRED TO INSERT CLIP
5. USE 80/20 JIG PART # 6075 TO DRILL THE 9/32" HOLE

ORTON DESIGN

CONNECTOR "H" - STANDARD END FASTENER

HALF

MATERIAL - 80/20 PART # 3380

ODJ127-46