



ASSEMBLY

NOTES:

1. GLUE BLOCK TO 1/4" PLYWOOD
2. PANEL INSET 1/8" BECAUSE IT LOOKS BETTER INSET
3. ELASTIC STOP NUTS USED DUE TO VEHICLE VIBRATIONS
4. NEED ACCESS BEHIND 80/20 FRAME TO BOLT ON PANEL
5. BOLT ON BLOCKS AND THEN GLUE PLYWOOD TO BLOCKS

*ORTON DESIGN*

CONNECTOR "G" – FIXED PANEL WOOD BLOCK

HALF

MATERIAL – 3/4" x 1 1/8" WOOD

ODJ127-48