



ASSEMBLY

NOTES:

1. ONE HOLE NOT CENTERED TO ALLOW NUT TO CLEAR OTHER CARRIAGE BOLT
2. USED TO BOLT 80/20 TO FLOOR
3. ELASTIC STOP NUT USED DUE TO VEHICLE VIBRATIONS
4. LOCATE SO ELEVATOR BOLT HEAD IS BETWEEN CORRUGATIONS OVER CLOSED CELL INSULATION
5. INSTALL ANGLE AND MARK HOLE LOCATION
6. REMOVE PLYWOOD AND DRILL THE 11/32" HOLES
7. USE CONSTRUCTION ADHESIVE UNDER BOLT HEAD AND TIGHTEN WITH A NUT FENDER WASHER TO HOLD

ORTON DESIGN

CONNECTOR "C" – FLOOR 90 DEGREE ANGLE

HALF

MATERIAL – 3/16 x 1 1/2" ALUMINUM ANGLE

ODJ127-41